

Generic Fault Output

SIGNAL SDS series irrigation controllers are equipped with a non-specific fault output. This output is a voltage free, normally open relay contact.

Whenever a SIGNAL controller (fitted with input sensors) detects a fault, the generic fault output will deliver a *one second* closed contact. This can be used to activate an external device including; siren, strobe-light, etc.

The output is located on the left-hand side of the controller terminal strip (refer to fig-1).




Fig-1

Interrogating the log of events found in the controller's Information-Menu will provide details, including the nature of the fault and fault time/date.